

Hadley Products

New Generation Horn Shield Replacement Instructions

Shield and bracket intended to be replaced with horn mounted on vehicle.

Step 1 - Remove the label from the face of the horn shield to expose rivets by raising up a corner of the label and peel off steadily.

Step 2 - Use a 1/8 inch diameter drill to remove three rivets securing the shield to the bracket. (refer to figure 1) The shield may be retained with a sealer also, which will require a steady pull on the shield to peel it off the bracket. Remove the shield from horn and discard.

Step 3 - Use a 1/8 inch diameter drill to remove the four rivets securing the bracket to horn bell. (refer to figure 2) Discard old bracket.

Step 4 - Position new bracket inside horn bell, align holes, and pop-rivet in place.

Step 5 - Position new shield over bracket and align holes. Install supplied pop-rivets.

Step 6 - Apply new supplied label, ensuring correct orientation.

Figure 1



Figure 2

