General Installation Instructions

CHROME-PLATED AIR COMPRESSOR H00850CA (INDIVIDUALLY PACKED) H00850CB (BULK PACKED)

IMPORTANT: REVIEW ALL INSTRUCTIONS, PARTS LISTS, & INSTALLATION DIAGRAMS BEFORE STARTING INSTALLATION

- 1. As shown in the bracket assembly diagram, slide the (2) grommets into slots. Next push the (2) brass eyelets into the grommets. Pull the (4) bumpers through the four round holes on the bracket.
- 2. Note: Mount compressor on rigid support. Do not mount on fender well, firewall or other flexible material. Locate compressor in an area with good air flow and away from excessive water and dirt conditions. Mounting requires two holes spaced 2 3/16in. apart, each having a diameter of 7/32in. as shown in the bracket assembly diagram.
- 3. To mount compressor, insert the 10-32 screw through the washer, brass eyelet, and the 7/32 hole. Secure with the 10-32 locknut and washer as shown in the diagram. **Do not overtighten mounting screws.**
- 4. Connect orange (+) wire of motor to a fused 20 amp circuit. Attach motor's black wire (-) to metal ground.

All Hadley products carry a limited warranty for 12 months from date of purchase. We will repair or replace, at our option, defects in material and workmanship during that period when product and proof of purchase are returned to our service department at the address below.



www.hadley-products.com

Hadley Products Attn: Service Department 2851 Prairie S.W. Suite D Grandville, MI 49418

Service Department: (616) 249-8462 Main: (616) 530-1717 Fax: (616) 530-3283

Page: 1 Rev. A/03 Filename: H16205.p65

BRACKET ASSEMBLY DIAGRAM \oplus \oplus 2 3/16 COMPRESSOR ø7/32 -MOUNTING TEMPLATE Ø7/32 PARTS LIST (2)-QUANTITY (2)-QUANTITY (2)-QUANTITY (4)-QUANTITY (2)-QUANTITY (4)-QUANTITY **SCREW EYELET** GROMMET **BUMPER** WASHER LOCKNUT H14572 H15289 H15224 H15234 H15291 H15290 (4)(6) PAGE 2 REV: A/03 FILENAME: H16205.DWG