

General Installation Instructions

Hadley Horn Kits

For Vehicles With Air Brakes

1. For best results mount horn in an unobstructed opening for sound to carry straight ahead. If possible mount with a slight downward angle to allow moisture to drain from horn.
2. If cab is equipped with roof trim panel, remove to install horn.
3. Drill $\frac{1}{2}$ " and $\frac{9}{32}$ " holes (using gasket for template) in position desired for horn base. Locate positions for front support and drill $\frac{9}{32}$ " holes.
4. Place gasket between base of horn and top of cab roof, and between support and top of cab roof.
5. Mount horn and support with $\frac{1}{4}$ " bolts, nuts, and lockwashers.
6. Connect tubing from air supply to horn air inlet.
7. NOTE: Manual valve or electronic solenoid valve must be used to control air supply to horn.

IMPORTANT: Use Pipe Compound on Pipe Threads to Assure Air Tight Connections.

CAUTION: Check local noise abatement ordinances to avoid legal violations.

All Hadley products carry a limited warranty for 12 months from date of purchase. We will repair or replace, at our option, defects in material and workmanship during that period when product is returned to our service department at the address below.

Hadley Products
Attn.: Service Department
2851 Prairie S.W., Suite D
Grandville, MI 49418

Service Department: (616) 249-8462
Main: (616) 530-1717
Fax: (616) 530-3283



Visit us on the web at www.hadley-products.com