

HADLEY PRODUCTS


INSTALLATION INSTRUCTIONS FOR CHECK VALVE

Using this check valve will provide an additional seal to maintain air tank pressure.

CAUTION: DO NOT MOUNT CHECK VALVE IN COMPRESSOR HEAD, OR UNIT WILL NOT OPERATE PROPERLY.

INSTRUCTIONS

1. Disconnect compressor air line from tank assembly.
2. Remove brass fitting #H12553 from current location.
3. Install brass check valve provided. Add pipe sealant to threads if check valve was not supplied with it.
4. Re-connect airline to check valve.



If you should have any questions about this installation, please contact the service department at Hadley Products. Service Direct Line (616)-249-8462

Hadley Products
2851 Prairie S.W. Suite D
Grandville, MI 49418
Main: (616) 530-1717
Fax: (616) 530-3283



www.hadley-products.com

Page 1 Rev: A/99
Filename: 15452.p65