

HCV INSTALLATION INSTRUCTIONS

Caution: Air lines are pressurized and may blow debris, USE EYE PROTECTION.

- 1. Disconnect and remove old valve.
- 2. Attach the Hadley H00500 HCV to the same mounting bracket. Or use the enclosed brackets as needed to mount the valve.
- 3. **Attach the proper length lever** to achieve 30° minimum fill and exhaust angle (see above notes). Check for any interference or straight lining of the valve lever and linkage through the entire suspension travel
- 4. Reconnect the air lines to the H00500 HCV per the picture above. Connect the dump pilot port to a normally closed control valve.
- 5. Adjust the ride height of the suspension utilizing the H00500 HCV lever and the vehicle manufacturer's ride height recommendations. Install centering dowel to insure the valve dead band is at ride height.
- 6. Tighten all nuts 60 to 80 in-lbs.
- 7. Remove centering dowel.


PROBLEM	POSSIBLE CAUSE
Air springs flat	Obstructed air line
	Insufficient air pressure to suspension
	Defective Pressure Protection Valve
	Defective HCV (see test procedure)
	Air leak in system
Air springs raise to full height but do not exhaust	Obstructed air line
	Defective HCV (see test procedure)
Air springs deflate when parked	Leak in air system (check with soapy water)
	Defective HCV (see test procedure)
Suspension will not maintain proper height	Check dump port for proper venting
	(see installation notes 3 & 4)
	Obstructed air line
	Defective HCV (see test procedure)
Hard ride	Ride height out of adjustment (readjust
	per vehicle service manual)
Ride height unequal side to side for (2) valve	Check dump port for proper venting
system	(see installation notes 3 & 4)
	Reset ride height on each side
	(per installation instruction 5)

HCV TEST PROCEDURE

- 1. With a minimum of 90 psi at the supply port, rotate the lever up (as indicated on the side of the valve) 30° to 45°. Air should begin to flow into the air springs within seconds.
- 2. Rotate the lever to the neutral postion. Air flow should stop.
- 3. Rotate the lever down 30° to 45° . Air should begin to exhaust from the air springs within seconds.
- 4. Rotate the lever to the neutral position. Air flow should stop.
- 5. If valve fails to flow air or shut off as specified, replace with a new one.

REASONS TO REPLACE THE HCV

- -HCV did not pass the test procedure
- -Air leaks from the HCV
- -HCV is damaged



HADLEY PRODUCTS 2851 Prairie St SW Grandville MI 49418 Telephone (616) 530-1717 Fax (616) 530-3283

Call or write regarding other Hadley products: Cab or Chassis HCV's, Air Horns, Mini Compressors, etc.

TYPICAL INSTALLATION

ELECTRIC SOLENOID AND REVERSE DUMP OPTIONS AVAILABLE